Boosters

TS004

Booster on ISOFIX plus the vehicle belt

100–150 cm; the ISOFIX connection holds the booster while the vehicle belt routes across the shoulder.

01 Full specification

Model	**TS004**
Height band	**100–150 cm**
Child weight	**—**
Fixing method	**Vehicle three-point belt**
Rotation	**Fixed**
Headrest positions	**—**
Recline positions	**—**
Main structure	**Blow-moulded one-piece plastic shell**
Restraint	**Vehicle three-point belt**
Product size	**43 × 24 × 53 cm**

Loading quantity

Carton	Product size	20GP	40GP	40HC
Standard carton	44.5 × 25.5 × 53.5 cm	495	990	1150

Loading quantities are units per 20GP / 40GP / 40HC container, for freight planning only; they are not stock figures.

02 Feature matrix

- **Three-point belt routing**
  The vehicle belt is guided across shoulder and hip, clear of neck and abdomen.
- **Blow-moulded shell**
  A one-piece moulded plastic body: fewer parts, lower weight.
- **Breathable fabrics**
  Soft, removable and washable, tested for flammability and toxicity.

03 Installation and use

Booster mode · 100–150 cm

01 Remove the five-point harness as described in the manual, keeping the seat and booster structure.

02 Seat the child, then route the vehicle belt through the shoulder and lap guides.

03 Confirm the shoulder section crosses the middle of the shoulder and the lap section sits on the hips, not the abdomen.

04 On models with rigid ISOFIX connectors, connect the seat first, then seat the child.

04 Approvals

Approvals

ECE R129