Top tether

CS806

Top-tether rotation, 15 headrest positions

Full 40–150 cm range, 360° rotation locked in four directions, rear-facing across 40–105 cm.

01 Full specification

Model	**CS806**
Height band	**40–150 cm**
Child weight	**0–36 kg**
Fixing method	**ISOFIX + top tether / Vehicle three-point belt**
Rotation	**360°**
Headrest positions	**15**
Recline positions	**4**
Main structure	**Blow-moulded one-piece plastic shell**
Restraint	**Five-point harness**
Product size	**49 × 43.8 × 58 cm**

Loading quantity

Carton	Product size	20GP	40GP	40HC
Standard carton	50 × 45 × 60 cm	192	400	495
L-shaped carton	50 × 45 × 60 cm	280	560	700

Loading quantities are units per 20GP / 40GP / 40HC container, for freight planning only; they are not stock figures.

02 Feature matrix

- **ISOFIX + top tether**
  The tether anchors to the seat-back point and limits forward rotation.
- **Rear-facing**
  In the rear-facing band the whole backrest takes the impact load.
- **Forward-facing**
  Turns forward once the child has the height, using the three-point belt.
- **360° rotation**
  Four lockable directions make side loading easier.
- **Five-point harness**
  Five load paths; the shoulder height follows the headrest.
- **Adjustable headrest**
  Multiple positions raising the shoulder slot with the headrest.
- **Adjustable recline**
  Four positions balancing newborn sleep and upright school-age posture.
- **Three-point belt routing**
  The vehicle belt is guided across shoulder and hip, clear of neck and abdomen.
- **Blow-moulded shell**
  A one-piece moulded plastic body: fewer parts, lower weight.
- **Breathable fabrics**
  Soft, removable and washable, tested for flammability and toxicity.

03 Installation and use

Rear-facing · 40–105 cm

01 Place the seat on the rear bench, extend the ISOFIX arms and push them into the anchorages until they latch.
02 Set the support leg until it contacts the vehicle floor and locks; on tether models, tighten the top tether instead.
03 Set the recline to the position you need and raise the headrest level with the child’s shoulders.
04 Tighten the five-point harness until you can only fit one finger between strap and shoulder.

Forward-facing · 100–150 cm

01 Turn the seat forward-facing and confirm it is locked in one of the four fixed directions.
02 Above 100 cm, route the vehicle three-point belt through the belt guides instead of the harness.
03 Raise the headrest step by step; the shoulder slot must never sit above the shoulder.
04 Check the belt is untwisted and taut, with the lap section flat across the hips.

04 Approvals

Approvals

ECE R129